




## #592 Digital Pedometer Instructions

Congratulations! You are the proud owner of a Freestyle® digital pedometer, which is one of the most accurate and versatile exercise instruments for the walker or runner today. Your new pedometer includes these useful features:

- STEP COUNTER
- DISTANCE CALCULATOR
- CALORIE COUNTER
- COUNT-DOWN TIMER
- AUTOMATIC COUNT-UP TIMER
- TIME/DAY/DATE
- STOPWATCH
- NIGHT VISION® ILLUMINATION
- RECALLS WEEKLY AND TOTAL RECORDS
- STEP PACER

### BUTTON CONFIGURATION



### BEFORE YOU BEGIN

Before using your Freestyle® digital pedometer, it is necessary to program the unit with your stride length and your weight. Accurate measurement of this data will allow you to achieve precise, individual results.

### MEASURING YOUR STRIDE LENGTH:

1. Walk or run twelve steps, marking the spot at the beginning of your first step.
2. Measure the distance travelled in feet or meters from the beginning of your first step to the end of your last step.
3. Compute your single stride length by dividing the total distance measured by twelve.

**Please note:** This pedometer uses both the Imperial and Metric Systems of measurement. To toggle between Imperial and Metric in any mode, simply press and hold the RESET button for five seconds. KM (metric) or MILE (imperial) should appear on screen.

### MEASURING YOUR STRIDE LENGTH:

1. Walk or run twelve steps, marking the spot at the beginning of your first step.
2. Measure the distance travelled in feet or meters from the beginning of your first step to the end of your last step.
3. Compute your single stride length by dividing the total distance measured by twelve.

EXAMPLE: For a total distance measuring 384 inches, the single stride length is:

$$\frac{384 \text{ in.}}{12} = 32.25 \text{ inches}$$

Round off your single stride length measurement to the nearest inch or cm. In this case, it would be 32 inches. Divide this by 12 again to convert it to feet. 32 divided by 12 is 2.66. Round it off to 2.7. This is your stride length which you will enter into the pedometer.

### MEASURING YOUR WEIGHT:

Using a bathroom scale, determine your weight in pounds or kilograms. Be sure to remove your shoes and excess clothing.

### PROGRAMMING YOUR FREESTYLE® DIGITAL PEDOMETER

After measuring your stride length and weight, it is necessary to program this data into your digital pedometer. **Please note:** This pedometer uses both the Imperial and Metric Systems of measurement. To toggle between Imperial and Metric in any mode, simply press and hold the RESET button for five seconds.

### SETTING YOUR STRIDE LENGTH:

1. Press the **MODE** button until the screen displays (DIST) mode. Press the **SET** button to enter the stride length setting mode.
2. This pedometer has a preset stride length of 2.0 Feet. Press the **SET** button to increase the stride length, or press the **RESET** button to

decrease the stride length. Press and hold buttons for rapid advance. If using Imperial, the increment is .05 FT. If using the Metric, the increment is one centimeter. Press the **MODE** button to exit this screen and return to **DIST** mode.

### SETTING YOUR WEIGHT:

1. Press the **MODE** button until the screen is in (KCAL) mode. Press the **SET** button to enter weight setting mode.
2. The preset weight is 100 pounds. Press the **SET** button to increase, or the **RESET** button to decrease the amount. After you have set your weight, press the **MODE** button to exit the weight setting mode and go back to (KCAL) mode.

### SETTING THE CLOCK:

Press the **MODE** button until the screen is in the (CLOCK) mode. Once in the (CLOCK) mode, press the **SET** button to enter the clock setting mode. When the screen begins to flash, press the **SET** button to set the minutes. Press the **RESET** button to set the hour. Please note that AM and PM is shown to the left of the time, with an "A" for AM and a "P" for PM. Press the **TOTAL** button to set the year. Press **SET** to advance the digits. Press the **TOTAL** button again to set the month. Press **SET** to advance the month digits. Press the **TOTAL** button a third time to set the day. Press **SET** to advance the digits. Once the clock is set, press the **MODE** button to exit the time setting mode and enter the (CLOCK) mode.

### SETTING THE ALARM/ CHIME/ 24 HOUR MODE:

In (CLOCK) mode, press the **TOTAL** button. "ALARM OFF" will appear on the screen. To turn the alarm on, press **RESET**. To set the alarm time, press **SET**. Press **SET** again to advance the minute digits. Press **RESET** to set the hour. By setting the alarm time, it has been automatically turned on, and the alarm icon will appear on the screen. To turn the alarm off, you must be in (CLOCK) mode. Press the **TOTAL** button until the alarm time appears on the screen. Press **RESET** and "ALARM OFF" will appear on the screen.

To turn on and off the chime from (CLOCK) mode, press **TOTAL** twice until "CHIME OFF" appears on the screen. Press **RESET** to toggle between chime on and off.


To toggle between 12 and 24 Hour modes, press **TOTAL** again until "CLOCK 12H" appears on the screen. Press **RESET** to switch to 24H mode. Press **RESET** to go back to 12H mode.

### USING YOUR FREESTYLE® DIGITAL PEDOMETER

After programming is complete, you are ready to use your Freestyle® digital pedometer.

### POSITIONING YOUR DIGITAL PEDOMETER:

1. Use the clip on the back of your pedometer to secure the unit to your belt, or the top or your shorts or pants.
2. For proper readings, it is important to position the unit as close to your hip area as possible.
3. Be sure that the pedometer is parallel to the ground, as this will aid in proper function, and allow easy visual access to the display. See drawing below:



After securing your digital pedometer as indicated above, begin walking or running. The "active" icon will appear after 5 steps in the top left corner of the display to let you know that the pedometer is active and counting your steps. The pedometer will count steps while exercising in any mode setting. The information from your exercise will automatically be recorded. The results may be accessed at any time by pressing the **MODE** button to view in the various modes.

### READING AND UNDERSTANDING THE VARIOUS MODES:

By pressing the **MODE** button, the display will change according to the mode selected. The purpose of each mode, and instructions on how to read the display are described below:

**(STEP) Mode:** This mode counts and displays the number of steps walked or run on the lower display. The upper line displays the steps per minute. This pedometer counts steps up to 99,999, at which point it automatically goes to zero. You can also activate the Step Pacer to keep a steady pace. Press the **SET** button and turn Step Pacer on by pressing **TOTAL**. Set the frequency with the **SET** button. This automatically sets the Step Pacer. Turn off the Step Pacer by pressing the **SET** button and press **TOTAL** to change the screen to say "pacer off". By pressing and holding the **RESET** button in this mode, you will reset all the recorded data.

**(DIST) Mode:** This mode displays the total distance travelled in miles (ML) or kilometers (KM) on the lower display.

The upper line displays the MPH or KMPH. This mode will record your distance up to 999.99 miles. Press and hold the **RESET** button at any time to reset the recorded data. This mode also includes an Auto Tracker feature that will let beep every mile you walk or run. To activate the **AUTO TRACKER** feature, press **SET** then press **TOTAL**.

**(KCAL) Mode:** This mode calculates an estimated calories burned based on the number of steps taken and your weight. The lower line displays the current calories consumed. The upper line displays the average calories consumed per minute.

**Please note:** While metabolic rates may vary among users, this display reading will provide a general idea of energy. The Kcal may be converted to other units as follows: 1 Kcal = 4184 Joules = 3.97 BTU (British Thermal Units). This pedometer counts your burned calories up to 99999 Kcals. Press and hold the **RESET** button at any time to reset the recorded data.

**(WALK) Timer Mode:** This mode automatically keeps track of elapsed time during exercising. The lower line displays the total elapsed time during exercise. The upper line displays interval elapsed time.

**(CLOCK) Mode:** This mode simply displays the date and time in a 12 or 24-hour format, showing AM or PM to the left of the time. Refer back to "Programming Your Freestyle Digital Pedometer" to learn how to set the time.

**(DOWN) Timer Mode:** This mode allows you to set a countdown timer. To set the timer, press the **SET** button. Press **RESET** to advance the hours. Press **SET** to advance the minutes. Press **TOTAL** to reset the time to zero. Press **MODE** to set the timer and go to (DOWN) mode. Press the **TOTAL** button to start and stop the timer. The upper line displays the total countdown time, and the lower line displays the time to zero.

### RECALLING WEEKLY AND TOTAL RECORDS

This pedometer has built in memory to record weekly and total records. When you are in (STEP), (DIST), (KCAL) or (WALK) modes, press the **TOTAL** button to show the weekly total. Press the **TOTAL** button again to show the overall total records. The overall total also shows how many days the total amount has been recording. To recall last week's memory, press the **TOTAL** button for five seconds. Press the **MODE** button to cycle through STEP/DIST/KCAL/WALK.

### AUTOMATIC ZERO RESET

PLEASE NOTE: This unit has an automatic zero function as follows:

1. At 12:00PM each day, when the "day" marker advances to the new day, the previous day's readings still remain on the display. The digits will be flashing. Press the **MODE** button to stop the flashing. After walking, new records are registered on the new day.
2. At 12:00PM each Sat, when the "day" marker moves to Sun, the previous week's readings still remain on the display and they will be flashing. Press the **MODE** button to stop flashing. After walking, new records are registered on the new week and previous week's records are transferred to last week's records.

### USING THE STOPWATCH AND PACER FUNCTIONS

To use these functions, press and hold the **MODE** button for 5 seconds until (PEDO) begins to flash. Press the **MODE** button again to choose (STOP-W) for the stopwatch or (PACER) for the pacer function.

### USING THE STOPWATCH

In (STOP-W) mode, press the **MODE** button to toggle between cumulative counting, represented by the "C" and lap counting, represented by the "L" on the upper line display. Once this is selected, press the **TOTAL** button to start and stop the stopwatch. When counting laps, press **RESET** to show the split time. Press **SET** to release the split time and resume the stopwatch. To reset the stopwatch, press **RESET** once to display (CLEAR DATA). Press **RESET** again to reset to zero. To exit the stopwatch mode, press and hold the **MODE** button for 5 seconds until it begins to flash. Press the **MODE** button again to select (PEDO) to go back to the normal pedometer functions.

### USING THE PACER

In (PACER) mode, press **SET** to select the pace frequency. Press **SET** again to advance the digits. Press **MODE** to go back to (PACER) mode. Press the **TOTAL** button to start and stop the pacer. The unit will beep according to the pace frequency you set. Walking with the beeps will ensure that you keep up with the pace you set. You can mute the pacer beeps by pressing **RESET** while the pacer is activated. Press **RESET** again to turn the pacer beeps back on. To reset the pacer, press **RESET** to display (CLEAR DATA). Press the **RESET** button again to reset to zero. To exit the pacer mode, press and hold the **MODE** button for 5 seconds until it begins to flash (PACER). Press the **MODE** button to select (PEDO) to go back to the normal pedometer functions.

### USING THE NIGHT VISION® ILLUMINATION

To activate the Night Vision® light, press the **LIGHT** button. The light will stay on for approximately 5 seconds before automatically turning off.

### REPLACING THE BATTERY:

The battery life is estimated at one year. If the pedometer displays erratic readings, or if the screen is difficult to read, the battery may need to be replaced as follows:

1. Remove the black logo plate on the front side of the pedometer with a screwdriver or similar tool. A small lip at the bottom of the cover is provided to help pry it open.
2. Remove and replace the battery with type CR2032 3V Panasonic or an equivalent. Be sure that the "+" side is up when the battery is inserted into the compartment.
3. Replace the battery cover and snap back into place.

### FREESTYLE U.S.A. LIMITED WARRANTY

Freestyle® products are warranted to the original purchaser to be free from defects in material and workmanship under normal use for a period of one year from the date of purchase. During the warranty period, and upon proof of purchase, the product will be repaired or replaced, without charge, for either parts or labor. The limited warranty is given by Freestyle U.S.A. and not the dealer from whom the product was purchased.

Should the product be defective, please return (postage paid) to:

Freestyle  
Attn: Individual Returns  
47-50 33rd Street  
Long Island City, NY. 11101

Include a brief description of the problem, and a copy of your purchase receipt showing it was purchased within the past year. Include your name, address and zip code. Please allow 30 days for return.

This warranty will not apply if product has been misused, abused or altered. Bending the unit and visible cracking of the face or display are presumed to be defects resulting from misuse.

Neither this warranty nor any other warranty, expressed or implied, or any other warranties of merchantability shall extend behind the warranty period. No responsibility is assumed for any incidental or consequential damages, including but not limited to mathematical accuracy of the product. Some states do not allow limitations on how long an implied warranty lasts. Some states do not allow the exclusion or limit incidental or consequential damage, so the above limitations or exclusions may not apply to you. The warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Should this product require service after the warranty has expired, please return to

Freestyle  
Attn: Individual Returns  
47-50 33rd Street  
Long Island City, NY. 11101

Include a brief description of the problem and a check or money order for \$15.00. Please include your name, mailing address, zip code and telephone number. Please allow 30 days for return.

FS592/03