Freestyle®

CONVERT

Model FS81200
Model FS81201

FEATURES

- 100 meters H2O
- Day/date
- EL backlight
- Chronograph
- Pre-set countdown timer
- Alarm
- Dual time

CONTROL BUTTONS

S1 - Start/stop button
S2 - Lap/reset button
S3 - Mode button
S4 - Light button



DISPLAY MODES

The watch has four display modes: HOME TIME (TIME), HOME TIME ALARM (ALM1), STOPWATCH (STW) and COUNTDOWN TIMER (TMR).

To change from one display mode to another, press S3 button once. The mode description will appear for 2 seconds before the selected mode is activated.

HOME AND FOREIGN DISPLAY

To display FOREIGN TIME, press S2 button when HOME TIME is displayed. The mode description (TM-2) will appear shortly before FOREIGN TIME is displayed. To change back to HOME TIME, press S2 button.

To display the daily FOREIGN TIME ALARM, press S2 button when HOME TIME ALARM is displayed. The mode description (ALM2) will appear shortly before FOREIGN TIME ALARM is displayed. To change back to HOME TIME ALARM, press S2 button.

TO SET THE TIME AND CALENDAR

1. Press S3 button to select time mode.
2. Press S2 button to toggle between HOME TIME and FOREIGN TIME mode to set.
3. Press and hold S2 button for two seconds until the “SET” message appears and the second digits blink.
4. Press S1 button to reset the second digits to 00.
5. Press S3 button, the minute digits will blink.
6. Press S1 button to set the minute digits. Holding down the button will speed up the process.
7. Press S3 button, the hour digits will blink.
8. Press S1 button to set the hour digits.
9. Follow the same pattern to set date, month, day (of the week), hour format and calendar format.
10. To set the hour format, press S1 button to toggle between 12-hour and 24-hour format. The P.M. indicator may be displayed to indicate the time period 12:00A.M. – 11:59 P.M. in 12-hour format.
11. To set the calendar format, press S1 button to toggle between M-D (month-date) and D-M (date-month) format.
12. After finish making all the settings, press S2 button to confirm.

NOTE: The chosen hour and calendar formats will apply to both HOME TIME mode and FOREIGN TIME mode.

NOTE: In FOREIGN TIME settings, only minutes, hours, date, month and day are open to setting.

TO SET THE ALARM TIME

1. Press S3 button to select alarm mode.
2. Press S2 button to toggle between HOME TIME ALARM and FOREIGN TIME ALARM mode to set.
3. Press and hold S2 button for two seconds until the “SET” message appears and the minute digits blink.
4. Press S1 button to set the minute digits. Holding down the button will speed up the process.
5. Press S3 button, the hour digits will blink.
6. Press S1 button to set the hour digits.
7. After finish making all the settings, press S2 button to confirm.

TO TURN ON/OFF THE ALARM AND HOURLY CHIME

In alarm mode,

1. Press S2 button to toggle between HOME TIME ALARM and FOREIGN TIME ALARM mode to set.
2. Press S1 button once to activate the alarm. Alarm indicator AL1/AL2 will appear.
3. Press again to activate the hourly chime. Chime indicator will appear.
4. Press the third time to activate both functions. Both of the indicators will appear.
5. Press the fourth time to deactivate both functions. Both of the indicators will disappear.

WHEN AN ALARM OR HOURLY CHIME GOES OFF

A tune will go off by the hour if the hourly chime function is activated.

An alarm tune will be emitted for around 20 seconds at the designated time when the alarm is activated. To stop the tune, press any button.

TO USE THE STOPWATCH

1. Press S3 button to select STOPWATCH mode.
2. The stopwatch will then be displayed in its current state – reset, running, or stopped.
3. To resume a counting, press S1 button to resume from where it left off.
4. To start a new counting, reset the stopwatch to zero first.
   Press S1 button to stop counting, then press S2 button to reset counter to zero.

For the measurement of elapsed time:
In STOPWATCH mode,

1. Press S1 button to start counting.
2. To stop counting, press S1 button once. Press S1 button again to resume from where it left off.
3. To reset to zero, press S1 button to stop counting, then press S2 button to reset the counter to zero.

For the measurement of split time:
In STOPWATCH mode,

1. Press S1 button to start counting.
2. While the stopwatch is running, press S2 button once to register a lap. The stopwatch is still running in the background.
   To display the currently accumulated time, press S2 button again.
3. Repeat the last step until all the laps have been registered.
4. To stop counting, press S1 button once. Press S1 button again to resume from where it left off.
5. To reset to zero, press S1 button to stop counting, then press S2 button to reset the counter to zero.

NOTE: You can leave the stopwatch running while switching over to other operating modes.

TO SET THE TIMER

1. Press S3 button to select TIMER mode.
2. Press S2 button to alter the timer setting among 1, 3, 5, 10, 15, 20, 25, 30, 45 and 60 minutes.

TO USE THE TIMER

In TIMER mode,

1. Press S1 button to start counting.
2. To stop counting, press S1 button once. Press S1 button again to resume from where it left off.
3. To reload the TIMER, press S1 button to stop counting and then press S2 button.
4. After reaching zero in a countdown, a tune will be emitted. To stop the tune, press any button, the TIMER will reload automatically.

NOTE: You can leave the timer running while switching over to other operating modes.

TO USE THE BACKLIGHT

Press S4 button to turn on the backlight for around three seconds.

WATER RESISTANCE GUIDE

WATER RESISTANCE	SUITABLE ATMOSPHERE
3 ATM / 50 METERS / 100 FEET / 30 METERS H2O	Suitable for washing hands and light splashing
5 ATM / 50 METERS / 165 FEET / 50 METERS H2O	Suitable for light swimming. E.g.: Bathing in a pool or low tide waters, but not suitable for diving
10 ATM / 100 METERS / 330 FEET / 100 METERS H2O	Suitable for most water sorts. E.g.: Swimming, surfing and snorkeling, but not suitable for deep water diving
20 ATM / 200 METERS / 660 FEET / 200 METERS H2O	Suitable for most water sports including deep water diving

FOLLOW THESE 8 TIPS TO GET THE MOST OUT OF YOUR NEW WATCH!

1. Never pull out the crown or operate the pushers/buttons under water.
2. Make sure your crown is returned to the original position before you expose your watch to water.
3. If your watch is exposed to saltwater it is very important to wash it thoroughly under tap water and wipe dry with a soft cloth. Keep it clean!
4. Severe impacts or drops may affect your watches water resistance and performance.
5. Avoid exposing your Freestyle watch to extreme temperatures such as in a hot shower, Jacuzzi, sauna or hot tub. The combination of extreme heat and water may cause your watch to lose some of its water resistance.
6. Avoid exposing your watch to chemicals, soaps or solvents as they deteriorate the water resist seals in your watch.
7. Never try to remove the caseback, leave this to a certified watch repair technician or Freestyle service center. This will help in preventing water leakage from improper battery replacement.
8. It is advisable to have your watch pressure tested annually and to re-furbish your watch every 2-3 years to extend the life of the watch.

LIMITED LIFETIME WARRANTY
Freestyle U.S.A. warrants, to the original purchaser, that its watches are free from defects in materials and workmanship for the lifetime of the watch (under normal use) from date of original purchase. The following are not covered under warranty: battery, strap/bracelet/ band and crystal.

Accidental breakage or damage due to normal wear or misuse of the product, including but not limited to the mathematical accuracy of the product, is not covered under this warranty. Some states do not allow limitations on how long an implied warranty lasts, or the exclusions of or limitations on consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may have other rights, which vary from state to state.

Under this warranty FREESTYLE will make any necessary repairs, if applicable, at no cost to you the consumer. Any repair needed that is not under warranty will be at the cost of you the consumer. Proof of purchase and / or original receipt it needed to validate your warranty.

Your warranty is voided by any servicing out by a non-authorized agent. Any other form of guarantee to you by the retailer is his / her responsibility. This warranty applies to watches purchased in the United States. For watches purchased outside the United States, please contact you authorized FREESTYLE dealer for warranty information.

Should the warranty on your watch no longer be valid or found to be voided, please see the enclosed mailing form (on this page or flipside) for replacement costs per item. Please do not include any special watchband or any other items of personal value in your shipment. Allow 30 days for processing and the return of your serviced watch.

visit our site
www.freestyleusa.com

Convert-01